

Komatsu Equipment and Engine Look Up

Use this template as a guide to find the correct engine and parts for your Komatsu equipment. Note that this is a guide and is not guaranteed to produce the exact parts needed for your engine. We encourage all customers to call one of our dedicated salesman at DK Engine Parts at 1-855-474-9400 or email us at sales@dkengineparts.com to ensure you are getting the correct parts. Thank you and please let us know how we can help!

<u>Equipment Type:</u>	<u>Page(s):</u>
Dozers	<u>2-5</u>
Dumpers	<u>6</u>
Excavators	<u>7-11</u>
Graders	<u>12</u>
Wheel Loaders	<u>13-15</u>

To Go Back to DK Engine Parts Home Page:

[Home Page](#)

To Inquire About Parts or Ask a Question:

[Contact Us](#)



Komatsu DOZER	Equipment Serial Number	Engine Model	Engine Serial No.	Website for Specific Engine Parts
D20PL-6 / D20PLL-6	60001-Up	4D95S-W-1F	23318-Up	Click Here for Your Engine
D20Q-6 / D20S-6	60001-Up	4D95S-W-1F	23318-Up	Click Here for Your Engine
D20P-7A / D20PG-7A	75001-78603	4D95S-1H	124813-Up	Click Here for Your Engine
D20PL-7	62001-62453	4D95S-1H	124813-Up	Click Here for Your Engine
D21A-6	60001-Up	4D95S-W-1G	23318-Up	Click Here for Your Engine
D21E-6	60001-Up	4D95S-W-1G	23318-Up	Click Here for Your Engine
D21P-6 / D21P-6A / D21P-6B	60001-Up	4D95S-W-1G	23318-Up	Click Here for Your Engine
D21PL-6	60001-Up	4D95S-W-1G	23318-Up	Click Here for Your Engine
D21S-6 / D21S-6A	60001-Up	4D95S-W-1G	23318-Up	Click Here for Your Engine
D21A-7 / D21AG-7 / D21PG-7A	75001-78603	4D95S-1J	124813-Up	Click Here for Your Engine
D21QG-7 / D21S-7	61001-61131	4D95S-1J	124813-Up	Click Here for Your Engine
D31A-16	25001-Up	4D105-3C	40138-Up	Click Here for Your Engine
D31A-17 / D31E-17	32001-Up	4D105-5H & 5T	106581-152519	Click Here for Your Engine
D31A-17 / D31E-17	32001-Up	4D105-5H & 5T	152520-Up	Click Here for Your Engine
D31E-18	40001-Up	6D95L-1AA	29222-Up	Click Here for Your Engine
D31E-20	40087-42000 & A40523-Up	6D95L-1AC-E	96999-Up	Click Here for Your Engine
D31E-20	40087-42000 & A40523-Up	S4D102E-1J	26200163-Up	Click Here for Your Engine
D31E-20	42001-Up	6D95L-1AC-E	96999-Up	Click Here for Your Engine
D31E-20	42001-Up	S4D102E-1J	26200163-Up	Click Here for Your Engine
D31EX-21 / D31PX-21	50001-Up	SAA4D102E-2B-4	26277757-Up	Click Here for Your Engine
D31P-16 / D31P-16A	25001-Up	4D105-3C	40138-Up	Click Here for Your Engine
D31P-17 / D31P-17A	32001-Up	4D105-5H	106581-152519	Click Here for Your Engine
D31P-17 / D31P-17A	32001-Up	4D105-5H	152520-Up	Click Here for Your Engine
D31P-18 / D31P-18A	40001-Up & 40765-Up	6D95L-1AA	29222-Up	Click Here for Your Engine
D31P-20 / PL, PLL-20	45001-Up	6D95L-1AC-E	96999-Up	Click Here for Your Engine
D31P-20A	45001-Up	6D95L-1AC-E	96999-Up	Click Here for Your Engine
D31P-20A	45001-Up	S4D102E-1J	26200163-Up	Click Here for Your Engine
D31Q-16 / D31S-16	25001-Up	4D105-3C	40138-Up	Click Here for Your Engine
D31Q-17 / D31S-17	32001-Up	4D105-5H	106581-152519	Click Here for Your Engine
D31Q-17 / D31S-17	32001-Up	4D105-5H	152520-Up	Click Here for Your Engine
D31Q-18 / D31S-18	40001-Up	6D95L-1AA	29222-Up	Click Here for Your Engine
D32E-1/P-1	75501-75717	S4D102E-1J	26200163-Up	Click Here for Your Engine
D32E-1/P-1	75718-Up	S4D102E-1J	26200163-Up	Click Here for Your Engine
D32E-1A/P-1A	76093-Up	S4D102E-1J	26200163-Up	Click Here for Your Engine
D37E-2 / D37P-2	1501-2500	6D95L-1BB	29245-Up	Click Here for Your Engine
D37E-2 / D37P-2	2501-Up	6D95L-1VV	69586-Up	Click Here for Your Engine
D37E-5	1606-3001-Up & A1924-Up	6D95L-1AC-E	96999-Up	Click Here for Your Engine
D37E-5	1606-3001-Up & A1924-Up	S4D102E-1J	26200163-Up	Click Here for Your Engine
D37EX-21 / D37PX-21	5001-Up	SAA4D102E-2B-4	26277757-Up	Click Here for Your Engine
D37P-5A	1543-3001-Up & 1649 Up	6D95L-1AC-E	96999-Up	Click Here for Your Engine
D37P-5A	1543-3001-Up & 1649 Up	S4D102E-1J	26200163-Up	Click Here for Your Engine
D38E-1/P-1	85501-85798	S4D102E-1J	26200163-Up	Click Here for Your Engine
D38E-1/P-1	85799-Up	S4D102E-1J	26200163-Up	Click Here for Your Engine
D38E-1A/P-1A	86239-Up	S4D102E-1J	26200163-Up	Click Here for Your Engine
D39E-1/P-1	95501-95871	S4D102E-1J	26200163-Up	Click Here for Your Engine
D39E-1/P-1	95872-Up	S4D102E-1J	26200163-Up	Click Here for Your Engine
D39E-1A/P-1A	96338-Up	S4D102E-1J	26200163-Up	Click Here for Your Engine
D39EX-21 / D39PX-21	1001-Up	SAA4D102E-2A	26277757-Up	Click Here for Your Engine
D40A-1 / PL-1	1501-Up	S4D105-1B/2B	18273-Up	Click Here for Your Engine
D40A-1 / PL-1	1501-Up	S4D105-3B	44579-Up	Click Here for Your Engine

Komatsu DOZER	Equipment Serial Number	Engine Model	Engine Serial No.	Website for Specific Engine Parts
D40AF-1A / D40PF-1A	2201-Up	S4D105-1B	18273-Up	Click Here for Your Engine
D40A-3 / AM-3 / F-3 / P-3	6001-Up	6D105-1M-P	15149-49999	Click Here for Your Engine
D40A-3 / AM-3 / F-3 / P-3	6001-Up	6D105-1M-P	50001-Up	Click Here for Your Engine
D40PF-3A / PL-3 / PLL-3	6001-Up	6D105-1M-P	15149-49999	Click Here for Your Engine
D40PF-3A / PL-3 / PLL-3	6001-Up	6D105-1M-P	50001-Up	Click Here for Your Engine
D41A-3 / 3A / 3C	6001-Up	6D105-1M-P	15149-49999	Click Here for Your Engine
D41A-3 / 3A / 3C	6001-Up	6D105-1M-P	50001-Up	Click Here for Your Engine
D41A-6	B20001-Up	S6D102E1-Z	30707205-Up	Click Here for Your Engine
D41E-3 / P-3	6001-Up	6D105-1M-P	15149-49999	Click Here for Your Engine
D41E-3 / P-3	6001-Up	6D105-1M-P	50001-Up	Click Here for Your Engine
D41E-6 / P-6	B20001-Up	S6D102E1-Z	30707205-Up	Click Here for Your Engine
D41E-6K / 6K-B	50001-Up	S6D102E-1BB	26200929-Up	Click Here for Your Engine
D41E-6K / 6K-B	50001-Up	S6D102E-1BB	26255384-Up	Click Here for Your Engine
D41S-3 / D41Q-3	6001-Up	6D105-1M-P	15149-49999	Click Here for Your Engine
D41S-3 / D41Q-3	6001-Up	6D105-1M-P	50001-Up	Click Here for Your Engine
D45A-1 / D45P-1	1501-Up	S4D105-1C	19078-Up	Click Here for Your Engine
D45A-1 / D45P-1 / D45S-1	1501-Up	S4D105-2C	19078-Up	Click Here for Your Engine
D45A-1 / D45P-1 / D45S-1	1501-Up	S4D105-3C	44579-Up	Click Here for Your Engine
D50A-16	65001-Up	4D130-1C-A	10544-Up	Click Here for Your Engine
D50A-17	60001-Up & 80001-Up	6D125-1A	10001-Up	Click Here for Your Engine
D50F-16 / S-16	65001-Up	4D130-1D/1F	10006-Up	Click Here for Your Engine
D50P / PL-17	60001-Up	6D125-1A	10001-Up	Click Here for Your Engine
D50P-16	65001-Up	4D130-1C-A	10544-Up	Click Here for Your Engine
D50P-16	65001-Up	SL4D130-1B	24224-Up	Click Here for Your Engine
D53A-16	65001-Up	4D130-1E	10544-Up	Click Here for Your Engine
D53A-17 / D53P-17	80001-Up	6D125-1C	10001-Up	Click Here for Your Engine
D53A-17 / D53P-17	80001-Up	6D125E-2D	61779-Up	Click Here for Your Engine
D53P-16	65001-Up	4D130-1E	10544-Up	Click Here for Your Engine
D53P-16	65001-Up	SL4D130-1C	24260-Up	Click Here for Your Engine
D53S-16	65001-Up	4D130-1F	10544-Up	Click Here for Your Engine
D53S-17	80001-Up	4D130-1H	28323-Up	Click Here for Your Engine
D57S-1	6501-Up	S4D130-1A	10006-21530	Click Here for Your Engine
D57S-1B	20001-Up	S6D108-1B	11731-Up	Click Here for Your Engine
D58E-1 / D58E-1B	80888-Up	6D125-1DD	21811-Up	Click Here for Your Engine
D58E-1 / D58E-1B	80888-Up	6D125E-2G	61779-Up	Click Here for Your Engine
D58P-1 / D58P-1B	80588-Up	6D125-1EE	21811-Up	Click Here for Your Engine
D58P-1 / D58P-1B	80588-Up	6D125E-2H	61779-Up	Click Here for Your Engine
D60A-6 / D60P, PL-6	20006-Up	NH-220-C1		Click Here for Your Engine
D60A-7 / D60P, PL-7	40001-Up	NH-220-C1		Click Here for Your Engine
D60A-8 / D60P-8 / D60S-8	45001-Up	6D125-1F	10001-Up	Click Here for Your Engine
D60E-6 / D60S-6	20006-Up	NH-220-C1		Click Here for Your Engine
D60E-7 / D60S-7	40001-Up	NH-220-C1		Click Here for Your Engine
D60F-8 / D60A-8A	45001-Up	S6D125-1F	10001-Up	Click Here for Your Engine
D61E-12 / D61P-12	1001-Up	S6D114E-1A	30456012-Up	Click Here for Your Engine
D61EX-12 / D61PX-12	1001-Up	S6D114E-1A	30456012-Up	Click Here for Your Engine
D65A-6 / D65E-6	20006-Up	NH-220-C1		Click Here for Your Engine
D65A-8 / D65E-8	45001-Up	6D125-1J	10001-Up	Click Here for Your Engine
D65E-12	60001-60941	6D125-1AM	47990-Up	Click Here for Your Engine
D65E-12	60942-Up	6D125E-2A	61779-Up	Click Here for Your Engine
D65E-7 / D65P-7 / D65S-7	40001-Up	NH220-C1-2KK	174428-Up	Click Here for Your Engine
D65EX-12	60001-60941	S6D125-1AG	51975-Up	Click Here for Your Engine

Komatsu DOZER	Equipment Serial Number	Engine Model	Engine Serial No.	Website for Specific Engine Parts
D65EX-12	60942-Up	S6D125E-2A	60863-Up	Click Here for Your Engine
D65EX-12-E	60942-Up	SA6D125E-3A	310314-Up	Click Here for Your Engine
D65P-6 / D65S-6	20006-Up	NH-220-C1		Click Here for Your Engine
D65P-8 / D65S-8	45001-Up	6D125-1K	10001-Up	Click Here for Your Engine
D65P-12 / D65PX-12	60001-60883	S6D125-1AG	51975-Up	Click Here for Your Engine
D65P-12 / D65PX-12	60884-Up	S6D125E-2A	60863-Up	Click Here for Your Engine
D65P-12-E / D65PX-12-E	60884-Up	SA6D125E-3A	310314-Up	Click Here for Your Engine
D65S-6	20006-Up	NH220-C1-1H	40447-Up	Click Here for Your Engine
D65S-6	20006-Up	NH220-C1-2H	100101-Up	Click Here for Your Engine
D66S-1	1001-Up	SA6D110-1F	50001-Up	Click Here for Your Engine
D68E-1	1001-Up	6D125-1JJ	21829-Up	Click Here for Your Engine
D68E-1A / D68P-1A	B1001-Up	NH-220-C1		Click Here for Your Engine
D68P-1	45990-Up	6D125-1JJ	21829-Up	Click Here for Your Engine
D70-LE	45200-Up	6D125-1AF	24586-Up	Click Here for Your Engine
D70LE-12	60001-Up	6D125-1AN	47990-Up	Click Here for Your Engine
D75A-1	50001-Up	S6D125-1FF	24781-Up	Click Here for Your Engine
D75S-2	1004-Up	NH220-C1-1K	8289-Up	Click Here for Your Engine
D75S-2	1004-Up	NH220-C1-2K	100101-Up	Click Here for Your Engine
D75S-3	7001-Up	NT06-C1-1D	134677-Up	Click Here for Your Engine
D75S-5	15001-Up	S6D125-1E	10006-23192	Click Here for Your Engine
D75S-5	15001-Up	S6D125-1E	23193-Up	Click Here for Your Engine
D75S-5	15001-Up	S6D125E-2J	60863-Up	Click Here for Your Engine
D80A-12 / D80E-12 / D80P-12	10001-24999	NH220-C1-1L	8019-Up	Click Here for Your Engine
D80A-18 / D80E-18	25001-Up	NT855-1B		Click Here for Your Engine
D80P-18	2001-Up	NT855-1A	139838-Up	Click Here for Your Engine
D83E-1 / D83-P1	1001-Up	S6D125-1GG	25851-Up	Click Here for Your Engine
D85A-12	10001-Up	NH220-C1-1L	8019-Up	Click Here for Your Engine
D85A-12	10001-Up	NH220-C1-2L	100101-Up	Click Here for Your Engine
D85A-12	10001-Up	NH220-C1-1L	8019-Up	Click Here for Your Engine
D85A-18	25001-Up	NT855-1B	139849-Up	Click Here for Your Engine
D85A-21	35001-36533	S6D125-1CC	22313-Up	Click Here for Your Engine
D85A-21E	36534-Up	S6D125E-2C	60863-Up	Click Here for Your Engine
D85A-21B	35001-36536	S6D125-1CC-C	22313-Up	Click Here for Your Engine
D85A-21B	36537-Up	S6D125E-2C	60863-Up	Click Here for Your Engine
D85C-21A / D85C-21D	36551-Up	S6D125E-2F	60863-Up	Click Here for Your Engine
D85E-18	25001-Up	NT855-1B	139849-Up	Click Here for Your Engine
D85E-21	35001-36533	S6D125-1CC	22313-Up	Click Here for Your Engine
D85E-21E	36534-Up	S6D125E-2E	60863-Up	Click Here for Your Engine
D85EX-15	10001-Up	SA6D125E-3B-7	310001-Up	Click Here for Your Engine
D85P-18	2001-Up	NT855-1B	139849-Up	Click Here for Your Engine
D85P-21	3001-3688	S6D125-1CC	22313-Up	Click Here for Your Engine
D85P-21E	3689-Up	S6D125E-2E	60863-Up	Click Here for Your Engine
D87E-2	P090001-Up	S6D125E-2		Click Here for Your Engine
D87P-2	P092001-Up	S6D125E-2		Click Here for Your Engine
D95S-1	1003-1999	S4D155-4		Click Here for Your Engine
D95S-2	2001-Up	NT855-1D	153623-Up	Click Here for Your Engine
D135A-1	10001-Up	SA6D125-1Q	28389-Up	Click Here for Your Engine
D135A-2	10301-Up	S6D140-1U	10001-Up	Click Here for Your Engine
D150A-1	5508-Up	S6D155-4A	10014-Up	Click Here for Your Engine
D155A-1	5508-Up	S6D155-4B	10016-Up	Click Here for Your Engine
D155A-2	50001-Up	S6D155-4S	52707-Up	Click Here for Your Engine

Komatsu DOZER	Equipment Serial Number	Engine Model	Engine Serial No.	Website for Specific Engine Parts
D155A-3	60001-Up	S6D140-1Z	17626-Up	Click Here for Your Engine
D155A-3	60001-Up	SA6D140E-2A	22537-Up	Click Here for Your Engine
D155A-5	65001-Up	SA6D140E-2A	22537-Up	Click Here for Your Engine
D155AX-3	60001-Up	S6D140-1Z	17626-Up	Click Here for Your Engine
D155AX-3	60001-Up	SA6D140E-2A	22537-Up	Click Here for Your Engine
D155AX-5	70001-UP	SA6D140E-2B	22537-Up	Click Here for Your Engine
D155AX-5	70001-UP	SA6D140E-3C	110001-Up	Click Here for Your Engine
D155S-1	1001-Up	S6D155-4E	15182-Up	Click Here for Your Engine
D155W-1	12128-Up	S6D155-4J	22144-Up	Click Here for Your Engine
D275A-2	10001-Up	S6D170-1L	14674-Up	Click Here for Your Engine
D275A-2	10001-Up	S6D170-1LW	14674-Up	Click Here for Your Engine
D275A-2	10001-Up	S6D170E-2A	17358-Up	Click Here for Your Engine
D275AX-5	20001-Up	SDA6D140E-3A-9	110001-Up	Click Here for Your Engine
D355A-3	1010-Up	S6D155-4C	10011-Up	Click Here for Your Engine
D355A-3	1010-Up	SA6D155-4A-35	20338-Up	Click Here for Your Engine
D355A-5	12622-Up	SA6D155-4A	50816-Up	Click Here for Your Engine
D355C-3	1106-Up			Please Contact Us 1-855-474-9400
D355C-3-A	23933-Up	SA6D140-2C-50	23933-Up	Click Here for Your Engine
D355C-3-DA	14263-Up	SA6D140-2C-50	23933-Up	Click Here for Your Engine
D375A-1	15001-Up	SA6D170-B-1B	10332-11045	Click Here for Your Engine
D375A-1	15001-Up	SA6D170-B-1B	11046-Up	Click Here for Your Engine
D375A-2	16001-Up	SA6D170-B-1J	13551-Up	Click Here for Your Engine
D375A-3	17001-17500	SA6D170E-2A	17353-Up	Click Here for Your Engine
D375A-3A / D375A-3AD	17501-Up	SA6D170E-2A	17353-Up	Click Here for Your Engine
D375A-3AD / D375A-3D	17001-Up	SA6D170E-2A	17353-Up	Click Here for Your Engine
D375A-5	18001-Up	SA6D170E-3A-7	310001-Up	Click Here for Your Engine
D455A-1	1002-Up	VTA1710-1B	433904-Up	Click Here for Your Engine
D475A-1	10001-Up	SA8V170-1A	10001-Up	Click Here for Your Engine
D475A-2	10201-Up	SA12V140-1E	10001-Up	Click Here for Your Engine
D475A-3RP	10601-Up	SA12V140-1B,1C	11797-Up	Click Here for Your Engine
D575A-2SD	10001-Up	SA12V170-1D-E	10024-Up	Click Here for Your Engine
D575A-2SR	10001-Up	SA12V170-1D	10024-Up	Click Here for Your Engine
D575A-3	10101-Up	SA12V170E-2A	10196-Up	Click Here for Your Engine
TD-15C	P061366-Up	S6D114-1		Click Here for Your Engine
TD-15E	U008001 - Up & P030501-Up	S6D114-1		Click Here for Your Engine

Komatsu DUMPER	Equipment Serial Number	Engine Model	Engine Serial No.	Website for Specific Engine Parts
HA250-1	60636-Up	S6D125-1B8	22230-Up	Click Here for Your Engine
HA250-3	303001-Up	S6D125-1B8	22230-Up	Click Here for Your Engine
HA270-1	65226-Up	S6D125-1B8	22230-Up	Click Here for Your Engine
HA270-3	313001-Up	S6D125-1B8	22230-Up	Click Here for Your Engine
HD205-3	1003-Up	S6D125-1R	16790-Up	Click Here for Your Engine
HD255-5	1001-Up	SA6D125E-2G	60721-Up	Click Here for Your Engine
HD320-2	1005-Up	NTA-855-1A	102754-Up	Click Here for Your Engine
HD320-3	2501-Up	NTA-855-1A	102754-Up	Click Here for Your Engine
HD325-3	1501-Up	KT1150-1B	114945-Up	Click Here for Your Engine
HD325-5	2001-Up & A3027-Up	SA6D140-1B	10185-Up	Click Here for Your Engine
HD325-6	5001-Up	SAA6D140E-3A	110003-Up	Click Here for Your Engine
HD325-6 / 6W	5001-Up	SA6D140-1FF	17739-Up	Click Here for Your Engine
HD325-6 / 6W	5001-Up	SAA6D140E-2A	22653-Up	Click Here for Your Engine
HD405-6	1001-Up	SAA6D140E-3A	110003-Up	Click Here for Your Engine
HD405-6	1001-Up	SAA6D140E-2A	22653-Up	Click Here for Your Engine
HD405-6	5001-Up	SAA6D140E-2A	22653-Up	Click Here for Your Engine
HD460-1	1002-Up	VT1710	576252-Up	Please Contact Us 1-855-474-9400
HD465-2	1102-Up	VTA1710	430077-Up	Click Here for Your Engine
HD465-3	2001-Up & A2060-Up	SA6D170-A-1C & 1E	10569-Up	Click Here for Your Engine
HD465-5	4001-Up	SA6D170-A-1T	14203-Up	Click Here for Your Engine
HD465-5	4001-Up	SAA6D170E-2A	17389-Up	Click Here for Your Engine
HD465-7	7001-Up	SAA6D170E-3F-8	310001-Up	Click Here for Your Engine
HD605-5	1001-Up	SAA6D170E-2A	17389-Up	Click Here for Your Engine
HD605-7	7001-Up	SAA6D170E-3F-8	310001-Up	Click Here for Your Engine
HD785-1L	1101-Up	KT2300-1	103559-Up	Click Here for Your Engine
HD785-1S	1002-Up	KT2300-1	103559-Up	Click Here for Your Engine
HD785-2	1501-Up	SA8V170-1B	10007-Up	Click Here for Your Engine
HD785-3	2001-Up	SA12V140-1C & 1D	10034-Up	Click Here for Your Engine
HD785-5	4001-Up	SA12V140-1	11640-Up	Click Here for Your Engine
HD785-5LC	A10224-Up	SAA12V140E-2		Click Here for Your Engine
HD985-3	1001-Up	SA12V140-1Q	10034-Up	Click Here for Your Engine
HD985-5	1021-Up	SA12V140-1U	11755-Up	Click Here for Your Engine
HD1200M-1	1005-Up	KTA2300		Please Contact Us 1-855-474-9400
HM300-1	1001-Up	SAA6D125E-3G-8W	310001-Up	Click Here for Your Engine
HM350-1	1001-Up	SAA6D140E-3J-8	110001-Up	Click Here for Your Engine
HM400-1	1001-Up	SAA6D140E-3B	110003-Up	Click Here for Your Engine

Komatsu EXCAVATORS	Equipment Serial Number	Engine Model	Engine Serial No.	Website for Specific Engine Parts
PC60-3	18001-Up	4D95L-1C	10001-Up	Click Here for Your Engine
PC60-5	20501-Up	4D95L-1K	15548-Up	Click Here for Your Engine
PC60L-5	7501-Up	4D95L-1K	15548-Up	Click Here for Your Engine
PC60U-5	4501-Up	4D95L-1K	15548-Up	Click Here for Your Engine
PC60-6	28001-Up	4D95L-1AA/1BB	49965-Up	Click Here for Your Engine
PC60L-6	8001-Up	4D95L-1AA/1BB	49965-Up	Click Here for Your Engine
PC60-7 / PC60-7B	45001-Up	4D95L-GG/W/BW	131803-Up	Click Here for Your Engine
PC60-7 / PC60-7B	45001-Up	4D95LE-2A	100005-Up	Click Here for Your Engine
PC60-7 / PC60-7B	45001-Up	S4D102E-1B	26200282-Up	Click Here for Your Engine
PC70-6	34101-Up	4D95L-1AA-7	49965-Up	Click Here for Your Engine
PC75UU-1	1001-Up	4D95L-1Z	41633-Up	Click Here for Your Engine
PC75UU-2	5001-Up	4D95L-1FF	131803-Up	Click Here for Your Engine
PC75UU-3	15001-Up	4D95LE-2B	100005-Up	Click Here for Your Engine
PC78MR-6-N	1001-Up	S4D95LE-3A-2	100001-Up	Click Here for Your Engine
PC78US-5-NA	1001-Up	4D95LE-2B	100005-Up	Click Here for Your Engine
PC78US-6-N	4001-Up	S4D95LE-3A-2	100001-Up	Click Here for Your Engine
PC78US-6-N	4001-Up	4D95LE-2C	100005-Up	Click Here for Your Engine
PC80-3	2001-Up	4D95L-1L	15941-Up	Click Here for Your Engine
PC90-1	1001-Up	4D95L-1CC	49965-Up	Click Here for Your Engine
PC100-1	10001-Up	S4D105-5A	100022-149999	Click Here for Your Engine
PC100-1	10001-Up	S4D105-5A	150001-Up	Click Here for Your Engine
PC100-2	13001-18000	S4D105-5B	100028-149999	Click Here for Your Engine
PC100-2	13001-18000	S4D105-5B	150001-Up	Click Here for Your Engine
PC100-3	18001-Up	6D95L-1A	10001-Up	Click Here for Your Engine
PC100-5 / 5C	28001-Up	S4D95L-1A	48797-Up	Click Here for Your Engine
PC100-6 / 6Z	40001-Up	S4D95L-1J	135080-Up	Click Here for Your Engine
PC100-6 / 6Z	40001-Up	S4D102E-1D	26200163-Up	Click Here for Your Engine
PC100L-3	12001-Up	6D95L-1A	10001-Up	Click Here for Your Engine
PC100L-6	15001-Up	S4D102E-1D	26200163-Up	Click Here for Your Engine
PC100L-6	15001-Up	S4D95L-1J	135080-Up	Click Here for Your Engine
PC120-2	14001-Up	S4D105-5B	100028-149999	Click Here for Your Engine
PC120-2	14001-Up	S4D105-5B	150001-Up	Click Here for Your Engine
PC120-3	18001-Up	6D95L-1B	10001-Up	Click Here for Your Engine
PC120-5	30001-Up	S4D95L-1B	48811-Up	Click Here for Your Engine
PC120-5	A40001-Up	S4D95L-1B	48811-Up	Click Here for Your Engine
PC120-5C	36601-Up	S4D95L-1G	102350-Up	Click Here for Your Engine
PC120-5M	36601-Up	S4D95L-1G	48811-Up	Click Here for Your Engine
PC120-5Z	36601-Up	S4D95L-1G	102350-Up	Click Here for Your Engine
PC120-6 / 6Z	45001-Up	S4D95L-1K	135080-Up	Click Here for Your Engine
PC120-6 / 6Z	45001-Up	S4D102E-1E	26200163-Up	Click Here for Your Engine
PC120LC-6	45001-Up	S4D102E-1E	26200163-Up	Click Here for Your Engine
PC128US-1 / UU-1	1001-Up	S4D102E-1F-US	26200163-Up	Click Here for Your Engine
PC128US-2 / UU-2	5001-Up	S4D102E-1V	26200163-Up	Click Here for Your Engine
PC130-5	36601-Up	S4D95L-1B	48811-Up	Click Here for Your Engine
PC130-6	45001-Up	S4D95L-1K	135080-Up	Click Here for Your Engine
PC130-6K	K30001-Up	S4D102E-1AE	26213103-Up	Click Here for Your Engine
PC138USLC-2	1001-Up	S4D102E-1V	26200163-Up	Click Here for Your Engine
PC150-1 / LC-1	1001-Up	6D105-1U	52271-Up	Click Here for Your Engine
PC150-3 / LC-3	3001-Up	S6D95L-1C	10001-Up	Click Here for Your Engine
PC150-5 / LC-5	6001-Up & A7001-Up	S6D95L-1GG	58644-Up	Click Here for Your Engine
PC150-6K / LC-6K	K30001-Up	SA4D102E-1AA	21240928-Up	Click Here for Your Engine

Komatsu EXCAVATORS	Equipment Serial Number	Engine Model	Engine Serial No.	Website for Specific Engine Parts
PC150LGP-6K	K35001-Up	SA4D102E-1AE	26213103-Up	Click Here for Your Engine
PC158USEL-2	10001-Up	S4D102E-1V	26200163-Up	Click Here for Your Engine
PC158USLC-2-WI	10001-Up	S4D102E-1V	26200163-Up	Click Here for Your Engine
PC160-6K	K30001-Up	SA4D102E-1AA	21240928-Up	Click Here for Your Engine
PC160LC-7	10001-Up	SAA4D102E-2E-4	26277757-Up	Click Here for Your Engine
PC180LC-3, LC-3K	1001-Up	S6D95L-1P	27750-Up	Click Here for Your Engine
PC180LLC-3, LLC-3K	1001-Up	S6D95L-1P	27750-Up	Click Here for Your Engine
PC180NLC-3K	1001-Up	S6D95L-1P	27750-Up	Click Here for Your Engine
PC180LC-6K	K30001-Up	SA4D102E-1AA	21240928-Up	Click Here for Your Engine
PC180NLC-6K	K30001-Up	SA4D102E-1AA	21240928-Up	Click Here for Your Engine
PC200-1	10001-Up	6D105-1F	12218-49999	Click Here for Your Engine
PC200-1	10001-Up	6D105-1F	50001-Up	Click Here for Your Engine
PC200-2 / LC-2	15001-Up	6D105-1F	12218-49999	Click Here for Your Engine
PC200-2 / LC-2	15001-Up	6D105-1F	50001-Up	Click Here for Your Engine
PC200-3 / LC-3	20001-Up	S6D105-B-1A	61481-Up	Click Here for Your Engine
PC200-5 / LC-5	45001-Up	S6D95L-1U	35360-Up	Click Here for Your Engine
PC200-5 / LC-5	A47282-A70000	S6D95L-1U	35360-Up	Click Here for Your Engine
PC200-5 / LC-5	A70001-Up	SA6D95L-1	35398-Up	Click Here for Your Engine
PC200-5C	45001-Up	S6D95L-1U-C	35360-Up	Click Here for Your Engine
PC200-5T	58019-Up	S6D95L-1KK	35360-Up	Click Here for Your Engine
PC200-5Z	45001-Up	S6D95L-1JJ	35360-Up	Click Here for Your Engine
PC200-6 / 6A / 6H-A	80001-Up	S6D95L-1MM	106426-Up	Click Here for Your Engine
PC200-6 / 6A / 6H-A	80001-Up	S6D102E-1C	26200929-Up	Click Here for Your Engine
PC200-6/LC-6	A80001-Up	SA6D95L-1		Click Here for Your Engine
PC200-6/LC-6	A82001-Up	S6D102-1		Click Here for Your Engine
PC200-6B	C10001-Up	S6D102E-1C-US	26202240-Up	Click Here for Your Engine
PC200CA-6 / C1 / U1	T10001-Up	S6D102E-1C	26202240-Up	Click Here for Your Engine
PC200EL-6K / EN-6K	K30001-Up	S6D102E-1AC	21180000-Up	Click Here for Your Engine
PC200LC-6	A83001-Up	S6D102E-1		Click Here for Your Engine
PC200LC-6 / LC-6H	80001-Up	S6D95L-1MM	106426-Up	Click Here for Your Engine
PC200LC-6 / LC-6H	80001-Up	S6D102E-1C	26200929-Up	Click Here for Your Engine
PC200LL-6	A85001-Up	S6D102E-1		Click Here for Your Engine
PC200-6Z / LC-6Z	80001-Up	S6D102E-1C-Z	26200929-Up	Click Here for Your Engine
PC200-6Z / LC-6Z	80001-Up	SAA6D95LE-1A-C	150915-Up	Click Here for Your Engine
PC200-6Z / LC-6Z	80001-Up	S6D95L-1MM-C	106426-Up	Click Here for Your Engine
PC200-7-W1	200001-Up	SAA6D102E-2C	26474903-Up	Click Here for Your Engine
PC200LC-7-US / W1	200001-Up	SAA6D102E-2C	26474903-Up	Click Here for Your Engine
PC200LC-7L	A86001-Up	SAA6D102E-2C	26474903-Up	Click Here for Your Engine
PC200LC-7B	C50001-Up	SAA6D102E-2C	26474903-Up	Click Here for Your Engine
PC200Z-6LE	A83001-Up	S6D102E-1		Click Here for Your Engine
PC210-3 / LC-3	K10001-Up	S6D105-1B	97284-Up	Click Here for Your Engine
PC210-6	30001-Up	S6D102E-1C	26200929-Up	Click Here for Your Engine
PC210-6	30001-Up	SAA6D95LE-1A	150915-Up	Click Here for Your Engine
PC210-6	30001-Up	S6D95L-1MM	106426-Up	Click Here for Your Engine
PC210-6K	K30001-Up	S6D102E-1AA	21180000-Up	Click Here for Your Engine
PC210-6K	K30001-Up	S6D102E-1AB	21295204-Up	Click Here for Your Engine
PC210LC-6	A80001-Up	SA6D95L-1		Click Here for Your Engine
PC210LC-6	A82001-Up	S6D102-1		Click Here for Your Engine
PC210LC-6	A83001-Up	S6D102E-1		Click Here for Your Engine
PC210LC-6K	K30001-Up	S6D102E-1AA	21180000-Up	Click Here for Your Engine
PC210LC-6K	K30001-Up	S6D102E-1AB	21295204-Up	Click Here for Your Engine

Komatsu EXCAVATOR	Equipment Serial Number	Engine Model	Engine Serial No.	Website for Specific Engine Parts
PC210-7K	K40001-Up	SAA6D102E-2C-KU	21494941-Up	Click Here for Your Engine
PC210LC-7K / PC210NLC-7K	K40001-Up	SAA6D102E-2C-KU	21494941-Up	Click Here for Your Engine
PC220-2 / PC220LC-2	11001-Up	S6D105-1G	12124-49999	Click Here for Your Engine
PC220-2 / PC220LC-2	11001-Up	S6D105-1G	50001-Up	Click Here for Your Engine
PC220-3	20001-Up	S6D105-1Z	62361-Up	Click Here for Your Engine
PC220LC-3 / NLC-3	20001-Up	S6D105-1Z	62361-Up	Click Here for Your Engine
PC220-5 / 5C	35001-Up	SA6D95L-1C	35398-Up	Click Here for Your Engine
PC220LC-5 / 5C	35001-Up	SA6D95L-1	35398-Up	Click Here for Your Engine
PC220LC-5 / 5C	A35401-A70000-Up	SA6D95L-1	35398-Up	Click Here for Your Engine
PC220-6 / 6Z / LC-6 / LC-6Z	50001-Up	SA6D95L-1J	111870-Up	Click Here for Your Engine
PC220-6 / 6Z / LC-6 / LC-6Z	50001-Up	SAA6D95LE-1B	150915-Up	Click Here for Your Engine
PC220-6 / 6Z / LC-6 / LC-6Z	50001-Up	SA6D102E-1C	26200467-Up	Click Here for Your Engine
PC220LC-6	A80001-Up	SA6D95L-1		Click Here for Your Engine
PC220LC-6	A82001-Up	SA6D102-1		Click Here for Your Engine
PC220LC-6	A83001-Up	SA6D102E-1		Click Here for Your Engine
PC220LL-6	A85001-Up	SA6D102E-1		Click Here for Your Engine
PC220LC-7	60001-Up	SAA6D102E-2C	26474903-Up	Click Here for Your Engine
PC220LC-7L	A86001-Up	SAA6D102E-2C	26474903-Up	Click Here for Your Engine
PC220-7-W1 / LC-7-W1	60001-Up	SAA6D102E-2C	26474903-Up	Click Here for Your Engine
PC228US-1T	11001-Up	S6D102E-1FL-S2	26200929-Up	Click Here for Your Engine
PC228USLC-1	11001-Up	S6D102E-1FL-S2	26200929-Up	Click Here for Your Engine
PC228USLC-2	15001-Up	S6D102E-1FL-S2	26200929-Up	Click Here for Your Engine
PC228US-2-KJ / US-2-US	15001-Up	S6D102E-1FL-S2	26200929-Up	Click Here for Your Engine
PC228USLC-3	20001-Up	SAA6D102E-2A	26274903-Up	Click Here for Your Engine
PC228US-3-KU / US-3-W1	20001-Up	SAA6D102E-2A	26274903-Up	Click Here for Your Engine
PC228UU-1-NZ	11001-Up	S6D102E-1F	26200929-Up	Click Here for Your Engine
PC230-6 / LC-6	10001-Up	SA6D102E-1C	26200467-Up	Click Here for Your Engine
PC230-6 / LC-6	10001-Up	SAA6D95LE-1B	150915-Up	Click Here for Your Engine
PC230-6 / LC-6	10001-Up	SA6D95L-1J	111870-Up	Click Here for Your Engine
PC240-3K / LC-3K / NLC-3K	K10001-Up	S6D105-1Z	97407-Up	Click Here for Your Engine
PC240-6K / LC-6K / NLC-6K	K30001-Up	S6D102E-1AA	21180000-Up	Click Here for Your Engine
PC240-6K / LC-6K / NLC-6K	K30001-Up	S6D102E-1AB	21296537-Up	Click Here for Your Engine
PC240LC-7K / NLC-7K	K40001-Up	SAA6D102E-2C-KU	21494941-Up	Click Here for Your Engine
PC250-6 / HD-6Z / LC-6	10001-Up	SA6D102E-1C	26200467-Up	Click Here for Your Engine
PC250LC-6	A80001-Up	SA6D95L-1		Click Here for Your Engine
PC250LC-6	A82001-Up	SA6D102-1		Click Here for Your Engine
PC250LC-6	A83001-Up	SA6D102E-1		Click Here for Your Engine
PC270LC-6	A83001-Up	SA6D102E-1		Click Here for Your Engine
PC270LC-7 / LC-7L / LC-7MH	A86001-Up	SAA6D102E-2C	26474903-Up	Click Here for Your Engine
PC280LC-3	10001-Up	S6D110-1D	55860-Up	Click Here for Your Engine
PC290LC-6K	K30001-Up	S6D102E-1AC	21288263-Up	Click Here for Your Engine
PC290NLC-6K	K30001-Up	S6D102E-1AC	21288263-Up	Click Here for Your Engine
PC290LC-7K / NLC-7K	K40001-Up	SAA6D102E-2C-KU	21494941-Up	Click Here for Your Engine
PC300-1	10001-Up	N855-1	162054-Up	Click Here for Your Engine
PC300LC-1	11001-Up	N855-1	162054-Up	Click Here for Your Engine
PC300-2 / LC-2	11001-Up	N855-1	162054-Up	Click Here for Your Engine
PC300-3 / LC-3	12001-Up - A14398-Up	S6D125-1S	13137-23688	Click Here for Your Engine
PC300-3 / LC-3	12001-Up - A14398-Up	S6D125-1S	23689-Up	Click Here for Your Engine
PC300-5 / HD-5K	20001-Up	SA6D108-1A	10001-Up	Click Here for Your Engine
PC300-5K / LC-5K / NLC-5K	K20001-Up	SA6D108-1A	10001-Up	Click Here for Your Engine
PC300LC-5	A30001-UP	SA6D114-1		Click Here for Your Engine

Komatsu EXCAVATOR	Equipment Serial Number	Engine Model	Engine Serial No.	Website for Specific Engine Parts
PC300LC-5	A70501-Up	SA6D108	SERIAL No.	Click Here for Your Engine
PC300-5T / LC-5 / LC-5T	20001-Up	SA6D108-1A	10001-Up	Click Here for Your Engine
PC300-5T / LC-5 / LC-5T	A20267-A30000	SA6D108-1A	10001-Up	Click Here for Your Engine
PC300-6 / 6-Z / LC-6 / LC-6Z	30001-Up	SAA6D108E-2A	19030-Up	Click Here for Your Engine
PC300LC-6 / HD-6LC	A80001-A83000	SA6D114E-1		Click Here for Your Engine
PC300LC-6 / HD-6LE	A83001-A84000	SA6D114E-1		Click Here for Your Engine
PC300LC-6LE / HD-6LE	A84001-Up	SA6D114E-1		Click Here for Your Engine
PC300LL-6	A84001-Up	SA6D114E-1		Click Here for Your Engine
PC300LC-7 / HD-7	40001-Up	SAA6D114E-2A-A	26800003-Up	Click Here for Your Engine
PC300LC-7L / HD-7L	A85001-Up	SAA6D114E-2A-A	26800003-Up	Click Here for Your Engine
PC300-7-W1 / LC-7-W1	40001-Up	SAA6D114E-2A-A	26800003-Up	Click Here for Your Engine
PC340-6K	K30001-Up	SA6D114E-1A	21212392-Up	Click Here for Your Engine
PC340LC-6K / NLC-6K	10001-Up	SAA6D108E-2A-P	19030-Up	Click Here for Your Engine
PC340LC-6K / NLC-6K	K30001-Up	SA6D114E-1A	21212392-Up	Click Here for Your Engine
PC340LC-7K	K40001-Up	SAA6D114E-2A-A	26800003-Up	Click Here for Your Engine
PC350-6 / LC-6	10001-Up	SAA6D108E-2A	19030-Up	Click Here for Your Engine
PC350-7-W1 / LC-7-W1	20001-Up	SAA6D114E-2A-A	26800003-Up	Click Here for Your Engine
PC360LC-3	10001-Up	S6D125-1S	13137-23688	Click Here for Your Engine
PC360LC-3	10001-Up	S6D125-1S	23689-Up	Click Here for Your Engine
PC360LC-5	20001-Up	SA6D108-1A	10058-Up	Click Here for Your Engine
PC380LC-6K	K30001-Up	SAA6D108E-2A-P	19030-Up	Click Here for Your Engine
PC380LC-6K	K30001-Up	SA6D114E-1A-KU	21212392-Up	Click Here for Your Engine
PC380LC-6K-J	10001-Up	SAA6D108E-2A-P	19030-Up	Click Here for Your Engine
PC400-1 / LC-1	10001-Up	NT855-1E	163093-Up	Click Here for Your Engine
PC400-3 / LC-3	11001-Up	S6D125-1T	13444-26690	Click Here for Your Engine
PC400-3 / LC-3	11001-Up	S6D125-1T	26691-Up	Click Here for Your Engine
PC400-5 / LC-5 / LC-5T	20001-Up - A20109-Up	S6D125-1VV	35323-48087	Click Here for Your Engine
PC400-5 / LC-5 / LC-5T	20001-Up - A20109-Up	S6D125-1VV	48088-Up	Click Here for Your Engine
PC400-5A / SC / ST	10351-Up	S6D125-1VV	35323-48087	Click Here for Your Engine
PC400-5A / SC / ST	10351-Up	S6D125-1VV	48088-Up	Click Here for Your Engine
PC400HD-5K	20001-Up	S6D125-1VV	47224-Up	Click Here for Your Engine
PC400LC-5	A40001-A70500	LTA10-C		Click Here for Your Engine
PC400LC-5A / 5T	10351-Up	S6D125-1VV	35323-48087	Click Here for Your Engine
PC400LC-5A / 5T	10351-Up	S6D125-1VV	48088-Up	Click Here for Your Engine
PC400-6 / 6C / 6Z	30001-Up	SA6D125E-2A	60721-Up	Click Here for Your Engine
PC400-6-T2 / LC6-T2	30001-Up	SAA6D125E-2D	210001-Up	Click Here for Your Engine
PC400LC-6 / LC-6Z	30001-Up	SA6D125E-2A	60721-Up	Click Here for Your Engine
PC400LC-6/HD-6	A80001-A83000	M11		Click Here for Your Engine
PC400LC-6/HD-6	A83001-Up	SA6D125E-2		Click Here for Your Engine
PC400LC/HD-6LK	A84001-A85000	SA6D125E-2		Click Here for Your Engine
PC400LC-7L	A86001-Up	SAA6D125E-3		Click Here for Your Engine
PC410-5 / LC-5	10001-Up	S6D125-1VV	35323-48087	Click Here for Your Engine
PC410-5 / LC-5	10001-Up	S6D125-1VV	48088-Up	Click Here for Your Engine
PC450-6-A1 / LC-6-A1	10001-Up	SA6D125E-2A	60721-Up	Click Here for Your Engine
PC450-6K	K30001-Up	MTA11	23555298-Up	Click Here for Your Engine
PC450-6K-J / LC-6K-J	10001-Up	SA6D125E-2A-KU	60721-Up	Click Here for Your Engine
PC450-6K-KE	32106-Up	SA6D125E-2A-C	60721-Up	Click Here for Your Engine
PC450-6-T2 / LC-6-T2	10001-Up	SAA6D125E-2D	210001-Up	Click Here for Your Engine
PC450LC-6K	K30001-Up	MTA11	23555298-Up	Click Here for Your Engine
PC450LC-6K-KE	32106-Up	SA6D125E-2A-C	60721-Up	Click Here for Your Engine
PC600-6A-KJ / 6A-W1	10001-Up	SA6D140E-3B	110001-Up	Click Here for Your Engine

Komatsu EXCAVATOR	Equipment Serial Number	Engine Model	Engine Serial No.	Website for Specific Engine Parts
PC600-6K	K30001-Up	SA6D140E-3B	110001-Up	Click Here for Your Engine
PC600-6KJ / 6-W1	10001-Up	N14	1-Up	Click Here for Your Engine
PC600LC-6 / 6-KJ / 6-W1	10001-Up	N14	1-Up	Click Here for Your Engine
PC600LC-6A-CA / KJ / W1	10001-Up	SA6D140E-3B	110001-Up	Click Here for Your Engine
PC650-1	10007-Up	S6D170-1A	10025-Up	Click Here for Your Engine
PC650-1	10007-Up	KT1150-1E	11709-Up	Click Here for Your Engine
PC650-3 / LC-3 / SE-3	10501-Up	SA6D140-1C	10420-UP	Click Here for Your Engine
PC650LC-3	A15001-Up	K19		Click Here for Your Engine
PC650-5 / E-5 / LC-5 / SE-5	20001-Up	SA6D140-1EE	17739-Up	Click Here for Your Engine
PC650LC-5	A25001-Up	K19		Click Here for Your Engine
PC710-5 / SE-5	10001-Up	SA6D140-1EE	17739-Up	Click Here for Your Engine
PC750-6 / LC-6 / SE-6 / SE-6K	10001-Up	SAA6D140-2B	22653-Up	Click Here for Your Engine
PC750-6-AW / LC-6 / SE-6	11001-Up	SAA6D140E-3E-8	110001-Up	Click Here for Your Engine
PC750LC-6K-01	K30001-Up	SAA6D140-2B	22653-Up	Click Here for Your Engine
PC750LC-6K-01 / SE-6K-01	K30001-Up	SAA6D140E-3G	110003-Up	Click Here for Your Engine
PC750SE-6K	K30001-Up	QSK19	37172929-Up	Click Here for Your Engine
PC750SE-6K / 6K-01	K30001-Up	SAA6D140E-2B	22653-Up	Click Here for Your Engine
PC800-6 / SE-6	30001-Up	SAA6D140E-2B	22653-Up	Click Here for Your Engine
PC800-6-AW / SE-6-AW	30001-Up	SAA6D140E-3E	110001-Up	Click Here for Your Engine
PC1000-1 / LC-1 / SE-1 / SP-1	10001-Up	SA6D170B-1F	11763-Up	Click Here for Your Engine
PC1000-1 / LC-1 / SE-1 / SP-1	10001-Up	SA6D170E-2B	17353-Up	Click Here for Your Engine
PC1100-6 / LC-6 / SP-6	10001-Up	SAA6D170E-2D	17389-Up	Click Here for Your Engine
PC1250-7	20001-Up	SAA6D170E-3E	310005-Up	Click Here for Your Engine
PC1250LC-7	20001-Up	SAA6D170E-3E	310005-Up	Click Here for Your Engine
PC1250SP-7	20001-Up	SAA6D170E-3E	310005-Up	Click Here for Your Engine
PC1600-1	10063-Up	SA6D140-1K/1L	11397-Up	Click Here for Your Engine
PC1600-1	10063-Up	SA6D140-1N/1P	17739-Up	Click Here for Your Engine
PC1600SP-1	10001-Up	SA6D140-2A/2B	23933-Up	Click Here for Your Engine
PC1800-6	10001-Up	SAA6D140-2D/2E	22653-Up	Click Here for Your Engine
PC1800-6-T2	10001-Up	SAA6D140E-3C,D-8	110001-Up	Click Here for Your Engine
PF55L-1	10001-Up	S6D105-B-1A	78996-Up	Click Here for Your Engine
PW60-3	2001-Up	4D95L-1G	16084-Up	Click Here for Your Engine
PW100-1	1003-Up	S4D105-5E	101262-149999	Click Here for Your Engine
PW100-1	1003-Up	S4D105-5E	150007-Up	Click Here for Your Engine
PW100-3	1601-2300	S6D95L-1D	15060-Up	Click Here for Your Engine
PW100-3	2301-Up	S6D95L-1W	36830-Up	Click Here for Your Engine
PW130-6K	K30001-Up	S4D95L-1M	135080-Up	Click Here for Your Engine
PW130ES-6K	K30545-Up	S4D102E-1AA	26213103-Up	Click Here for Your Engine
PW150-1	1001-Up	6D95L-1C	10001-Up	Click Here for Your Engine
PW150ES-6K	K30001-Up	SA4D102E-1AC	21240928-Up	Click Here for Your Engine
PW170ES-6K	K30001-Up	SA4D102E-1AB	21271444-Up	Click Here for Your Engine
PW170ES-6K-KA	K30001-Up	SA4D102E-1AB	21240928-Up	Click Here for Your Engine
PW200-7K	K40001-Up	SAA6D102E-2-PW	21494941-Up	Click Here for Your Engine
PW210-1	10001-Up	S6D105-1VV	86432-Up	Click Here for Your Engine
PW400MH-6	A84210-Up	6D125E-2		Click Here for Your Engine

Komatsu GRADER	Equipment Serial Number	Engine Model	Engine Serial No.	Website for Specific Engine Parts
GD300-A	2001-Up	4D105-5J	102876-Up	Click Here for Your Engine
GD305-A-1A	6734-Up	6D95L-1HH	96999-Up	Click Here for Your Engine
GD405A-1	16877-Up	6D105-1P	16877-49999	Click Here for Your Engine
GD405A-1	16877-Up	6D105-1P	50001-Up	Click Here for Your Engine
GD500R-1	S4D130-1	I3734-Up		Click Here for Your Engine
GD505A-2	50003-Up	S6D105-1F	12124-49999	Click Here for Your Engine
GD505A-2	50003-Up	S6D105-1F	50001-Up	Click Here for Your Engine
GD510R-1	15001-Up	S6D95L-1Q	27756-Up	Click Here for Your Engine
GD511A-1	10001-Up	S6D95L-1L	22170-Up	Click Here for Your Engine
GD515A-1	50001-Up	S6D105-1YY	91468-Up	Click Here for Your Engine
GD521A-1E	12001-Up	S6D102E-1T	26200929-Up	Click Here for Your Engine
GD525A-1 / GD525A-1B	50001-Up	S6D105-1KK	10281-Up	Click Here for Your Engine
GD525A-1C	60001-Up	S6D105-1ZZ	91468-Up	Click Here for Your Engine
GD530A/AW-2A/2B/2C	202002-Up	S6D102-1		Click Here for Your Engine
GD530A/AW-2B/2C	203163-Up	S6D102E-1		Click Here for Your Engine
GD530A-1/AW-1	200840-201999	S6D102E-1		Click Here for Your Engine
GD530A-1E	201404-Up	S6D102-1		Click Here for Your Engine
GD555-3A	10001-Up	SA6D102E-1-GD	46018290-Up	Click Here for Your Engine
GD555-3C	50001-Up	SA6D102E-1-GD	46018290-Up	Click Here for Your Engine
GD600R-3	14001-Up	6D125-1N	10001-Up	Click Here for Your Engine
GD605A-2	53001-Up & 56001-Up	NH-220-C1		Click Here for Your Engine
GD605A-3	54001-Up	6D125-1Q	10001-Up	Click Here for Your Engine
GD605A-3US	57001-Up	6D125-1Q	10001-Up	Click Here for Your Engine
GD611A-1	10001-Up	S6D105-1PP	81520-Up	Click Here for Your Engine
GD615A-1	50001-Up	S6D110-1E	56348-Up	Click Here for Your Engine
GD621A-1 / GD621R-1	10001-Up	S6D105-1PP	81520-Up	Click Here for Your Engine
GD623A-1	30001-Up	6D125-1Z	19761-Up	Click Here for Your Engine
GD625A-1	50001-Up	6D125-1Y	10276-Up	Click Here for Your Engine
GD625A-1C	60001-Up	6D125-1AB	10276-Up	Click Here for Your Engine
GD625A-1C	60001-Up	6D125-1AB-N	47990-Up	Click Here for Your Engine
GD650A/AW-1	200840-201999	S6D114-1		Click Here for Your Engine
GD650A/AW-2A/2B/2C	202002-Up	S6D114-1		Click Here for Your Engine
GD650A/AW-2B/2C	202002-Up	S6D114E-1A	30456012-Up	Click Here for Your Engine
GD650A/AW-2B/2EY	210098-Up	S6D114E-1		Click Here for Your Engine
GD650A-2	202001-Up	S6D114-1		Click Here for Your Engine
GD655-3A	10001-Up	SA6D114E-1-GD	45992604-Up	Click Here for Your Engine
GD655-3C	50001-Up	SA6D114E-1-GD	30456012-Up	Click Here for Your Engine
GD655-3C-VH	50001-Up	SA6D114E-1-GD	45992604-Up	Click Here for Your Engine
GD655A-2	63001-Up & 66001-Up	NH-220-C1		Click Here for Your Engine
GD655A-3	64001-Up	6D125-1R	10001-Up	Click Here for Your Engine
GD655A-5	65001-Up	S6D105-1	72681-Up	Click Here for Your Engine
GD661A-1	10001-Up	S6D105-1NN	81519-Up	Click Here for Your Engine
GD670A/AW-1	200840-201999	S6D114-1		Click Here for Your Engine
GD670A/AW-2B/2C	202002-Up	S6D114-1		Click Here for Your Engine
GD675-3A	10001-Up	SA6D114E-1-GD	45992604-Up	Click Here for Your Engine
GD675-3C	50001-Up	SA6D114E-1-GD	45992604-Up	Click Here for Your Engine
GD705A-3	10002-Up	NT06-CI-1M	177873-Up	Click Here for Your Engine
GD705A-4R	21001-Up	S6D125-1C	10001-Up	Click Here for Your Engine
GD705A-4	21001-Up	S6D125-1D-AR	10001-Up	Click Here for Your Engine
GD725A-1	50001-Up	S6D125-1EE	10001-Up	Click Here for Your Engine
GD750A-1	7003-Up	M11		Click Here for Your Engine
GD825A-1	10002-Up	S6D140-1B	10278-Up	Click Here for Your Engine
GD825A-2	11001-Up	S6D140-1W	17626-Up	Click Here for Your Engine
GD825A-2	11001-Up	S6D140E-2B	23227-Up	Click Here for Your Engine
538	U0030001-U003100/C003101-Up	S6D114-1		Click Here for Your Engine
850	U200000-U200416	S6D114-1		Click Here for Your Engine
850	U200417-U201999	S6D114-1		Click Here for Your Engine
850/B/C, 870/B/C	U202002-Up	S6D114-1		Click Here for Your Engine
870	U200000-U200416	S6D114-1		Click Here for Your Engine
870	U200417- U201999	S6D114-1		Click Here for Your Engine

Komatsu WHEEL LOADER	Equipment Serial Number	Engine Model	Engine Serial No.	Website for Specific Engine Parts
WA40-1	1001-Up	4D95L-W-1A	10001-Up	Click Here for Your Engine
WA65-5	H50051-Up	4D95LE-3-65		Click Here for Your Engine
WA70-1	10001-Up	4D95L-W-1B	11437-Up	Click Here for Your Engine
WA70-1	10001-Up	4D95L-W-1E	11437-Up	Click Here for Your Engine
WA70-5	H50051-Up	4D95LE-3-65		Click Here for Your Engine
WA80-5 (20Km/h)	H50051-Up	4D95LE-3-65		Click Here for Your Engine
WA80-5 (30Km/h)	H50051-Up	4D95LE-3-65		Click Here for Your Engine
WA80-5	H50051-Up	4D95LE-3-65		Click Here for Your Engine
WA100 / WA100-3	10001-Up	6D95L-1L	10001-Up	Click Here for Your Engine
WA120-1	10001-Up	6D95L-1Z	26324-Up	Click Here for Your Engine
WA120-1LC	A20001-Up	S4D102E-1		Click Here for Your Engine
WA120-3	50001-52999	6D95L-1AF-1	96999-Up	Click Here for Your Engine
WA120-3 Avance Plus	A31001-Up	S4D102E-1		Click Here for Your Engine
WA120-3L	A30001-Up	S4D102E-1		Click Here for Your Engine
WA120L-3	54001-Up	S4D102E-1N-L	26200163-Up	Click Here for Your Engine
WA150-1 / 1A	10001-Up	S6D95L-1B	10001-Up	Click Here for Your Engine
WA180-1	10001-Up & A10375-Up	S6D95L-1M	26330-Up	Click Here for Your Engine
WA180-1LC	A75001-Up	S6D102-1		Click Here for Your Engine
WA180-3 / 3X	50001-52999	S6D95L-1NN-18	106426-Up	Click Here for Your Engine
WA180-3 / 3A	53001-Up	S6D102E-1W-D	26200929-Up	Click Here for Your Engine
WA180-3 Avance Plus	A81001-Up	S6D102E-1		Click Here for Your Engine
WA180-3 Avance Plus PTC	A85001-Up & A88001-Up	S6D102E-1		Click Here for Your Engine
WA180-3L	A80001-Up	S6D102E-1		Click Here for Your Engine
WA180L-3	54001-Up	S6D102E-1W-L	26200929-Up	Click Here for Your Engine
WA180PT-3	50001-Up	S6D102E-1W-PT	26200929-Up	Click Here for Your Engine
WA200-1 / 1A	10001-Up	6D105-1BB	62390-Up	Click Here for Your Engine
WA200-1	10001-Up	6D105-1Z	62390-Up	Click Here for Your Engine
WA250-1	10001-Up & A10509-Up	S6D105-1TT	86423-Up	Click Here for Your Engine
WA250-1LC	A65001-Up	S6D102-1		Click Here for Your Engine
WA250-3 / 3X	50001-52999	S6D95L-1PP-25	106426-Up	Click Here for Your Engine
WA250-3 Avance Plus	A71001-Up	S6D102E-1		Click Here for Your Engine
WA250-3 Avance Plus PTC	A78001-Up	S6D102E-1		Click Here for Your Engine
WA250-3A	53001-Up	S6D102E-1X	26200929-Up	Click Here for Your Engine
WA250-3L	A70001-Up	S6D102E-1		Click Here for Your Engine
WA250-3L PTC	A75001-Up	S6D102E-1		Click Here for Your Engine
WA250L-3	53001-Up	S6D102E-1		Click Here for Your Engine
WA250L-3-KM	53001-Up	S6D102E-1X-L	26200929-Up	Click Here for Your Engine
WA250PT-3	50001-Up	S6D102E-1X	26200929-Up	Click Here for Your Engine
WA300-1 / 1A	10001-Up	S6D105-1WW	63244-Up	Click Here for Your Engine
WA300-1 / 1A	10001-Up	S6D105-1X	63244-Up	Click Here for Your Engine
WA300L-3	53001-Up	SA6D102E-1B	26200467-Up	Click Here for Your Engine
WA320-1	10001-Up	S6D105-1AJ	86535-Up	Click Here for Your Engine
WA320-1 / 1R	10001-Up	S6D105-1SS	86535-Up	Click Here for Your Engine
WA320-1LC	A25001-Up	S6D114-1		Click Here for Your Engine
WA320-3	53001-Up	S6D108-1G	13936-Up	Click Here for Your Engine
WA320-3 Avance Custom	50001-Up	SA6D102E-1B	26200467-Up	Click Here for Your Engine
WA320-3 Avance Plus	A31001-Up	SA6D114E-1		Click Here for Your Engine
WA320-3CS / 3DZ	50001-Up	SA6D102E-1B-C	26200467-Up	Click Here for Your Engine
WA320-3H	20051-20560	SAA6D114		Please Contact Us 1-855-474-9400
WA320-3H Active	20561-Up	SAA6D114	Thru-21301476	Click Here for Your Engine
WA320-3H Active	20561-Up	SAA6D114	21301477-Up	Click Here for Your Engine

Komatsu WHEEL LOADER	Equipment Serial Number	Engine Model	Engine Serial No.	Website for Specific Engine Parts
WA320-3L	A30001-Up	S6D114E-1	SERIAL No.	Click Here for Your Engine
WA320-3-X / 3-XR	50001-52999	S6D108-1G	13936-Up	Click Here for Your Engine
WA350-1 / 1B / 1M	10001-Up & A11604-Up	S6D110-1A/1B	50195-Up	Click Here for Your Engine
WA380-1	10001-Up & A20012-Up	SA6D110-1Q	54352-Up	Click Here for Your Engine
WA380-1	10001-Up & A20012-Up	SA6D110-1U	54352-Up	Click Here for Your Engine
WA380-1LC	A45001-Up	S6D114-1		Click Here for Your Engine
WA380-3 / 3X	50001-52999	S6D108-1F	13936-Up	Click Here for Your Engine
WA380-3	53001-Up	S6D108-1F	13936-Up	Click Here for Your Engine
WA380-3 Avance Plus	A51001-Up	SA6D114E-1		Click Here for Your Engine
WA380-3H	20051-20500	S6D108-1		Click Here for Your Engine
WA380-3H Active	20501-Up	SAA6D114	Thru-21301476	Click Here for Your Engine
WA380-3H Active	20501-Up	SAA6D114	21301477-Up	Click Here for Your Engine
WA380-3L	A50001-Up	S6D114E-1		Click Here for Your Engine
WA380-5 / 5-W	60001-Up	SAA6D114E-2B-A	26800003-Up	Click Here for Your Engine
WA380-5L	A52001-Up	SAA6D114E-2B-A	26800003-Up	Click Here for Your Engine
WA400-1 / 1A	10001-Up	SA6D110-1K	50202-Up	Click Here for Your Engine
WA400-5	70001-Up	SAA6D114E-2B-A	26800003-Up	Click Here for Your Engine
WA400-5L	A40001-Up	SAA6D114E-2		Click Here for Your Engine
WA420-1	10001-Up	SA6D110-1R	54110-Up	Click Here for Your Engine
WA420-1	10001-Up	SA6D110-1W	54110-Up	Click Here for Your Engine
WA420-1LC	A25001-Up	SA6D114-1		Click Here for Your Engine
WA420-3	50001-Up	SA6D108-1G	16016-Up	Click Here for Your Engine
WA420-3	53001-Up	SA6D108-1G	16016-Up	Click Here for Your Engine
WA420-3 Avance Plus	A31001-Up	SAA6D114E-1		Click Here for Your Engine
WA420-3CS	R50001-Up	SA6D114-1AA	21271827-Up	Click Here for Your Engine
WA420-3H	30051-30296			Please Contact Us 1-855-474-9400
WA420-3H Active	30297-Up	SAA6D114E-1		Click Here for Your Engine
WA420-3L	A30001-Up	SAA6D114E-1		Click Here for Your Engine
WA420-3X / 3X-R	50001-52999	SA6D108-1G	16016-Up	Click Here for Your Engine
WA450-1 / 1A	10001-Up & A20038-Up	S6D125-1KJ & 1M	11574-Up	Click Here for Your Engine
WA450-2	A25001-Up	L10	34668922-Up	Click Here for Your Engine
WA450-3	53001-Up	SA6D125E-2C-L	60721-Up	Click Here for Your Engine
WA450-3 Avance Plus	A31001-Up	SA6D125E-2		Click Here for Your Engine
WA450-3A-TW	53001-Up	SA6D125E-2C-TA	85399-Up	Click Here for Your Engine
WA450-3L	53001-Up	S6D125-1AM	51975-Up	Click Here for Your Engine
WA450-3LL	50305-Up	S6D125-1AJ-S	51975-Up	Click Here for Your Engine
WA450-5L	A36001-Up	SAA6D125E-3		Click Here for Your Engine
WA450L-3	A30001-Up	M11		Click Here for Your Engine
WA450L-3	53001-Up	SA6D125E-2C-L	60721-Up	Click Here for Your Engine
WA470-1	10001-Up	S6D125-1LK	26750-Up	Click Here for Your Engine
WA470-1	10001-Up	S6D125-1Z	21431-Up	Click Here for Your Engine
WA470-3	53001-Up	S6D125-1AM	51975-Up	Click Here for Your Engine
WA470-3X	50001-52999	S6D125-1AM	51975-Up	Click Here for Your Engine
WA470-3H	H20051-20668	S6D125-1		Click Here for Your Engine
WA470-3H Active	H20669-20941	M11		Click Here for Your Engine
WA470-3H Active	H20942-Up	SA6D125E-2		Click Here for Your Engine
WA470-5H	50051-Up	SAA6D125E-3		Click Here for Your Engine
WA470-5-W	70001-Up	SAA6D125E-3A-W	310001-Up	Click Here for Your Engine
WA480-5L	A37001-Up	SAA6D125E-3		Click Here for Your Engine
WA480-5-W	80001-Up	SAA6D125E-3B-W	310001-Up	Click Here for Your Engine
WA500-1 / 1A	10001-Up & A20131-Up	S6D140-1A	10001-Up	Click Here for Your Engine

Komatsu WHEEL LOADER	Equipment Serial Number	Engine Model	Engine Serial No.	Website for Specific Engine Parts
WA500-1 / 1A	10001-Up & A20131-Up	S6D140-1R	10001-Up	Click Here for Your Engine
WA500-1L	A20854-Up	S6D140-1		Click Here for Your Engine
WA500-1LC	A60001-Up	NTA855		Please Contact Us 1-855-474-9400
WA500-1LE	A61001-Up	N14		Click Here for Your Engine
WA500-3	50001-Up	S6D140E-2A	23227-Up	Click Here for Your Engine
WA500-3	50001-Up	SA6D140E-3E-7	110001-Up	Click Here for Your Engine
WA500-3H	20051-Up	SAA6D140E-3		Click Here for Your Engine
WA500-3L	A70001-Up	N14		Click Here for Your Engine
WA500-3LK	A71001-Up	SAA6D140E-3		Click Here for Your Engine
WA600-1 / 1A / 1H	10001-Up & A10081-Up	S6D170-1D	10490-16040	Click Here for Your Engine
WA600-1 / 1A / 1H	10001-Up & A10081-Up	S6D170-1D	16041-Up	Click Here for Your Engine
WA600-1A / 1H	10001-Up	S6D170-1D-W	14674-Up	Click Here for Your Engine
WA600-1L	A10391-Up	S6D170-1		Click Here for Your Engine
WA600-1LC	A50001-Up	K19		Click Here for Your Engine
WA600-1LE	A51001-Up	QSK19		Click Here for Your Engine
WA600-3 / 3C / 3D	50001-Up	SA6D170E-2C	17353-Up	Click Here for Your Engine
WA600-3 / 3C / 3D	50001-Up	SAA6D170E-3A/3D	310005-Up	Click Here for Your Engine
WA600-3L	A52001-Up	QSK19		Click Here for Your Engine
WA600-3LK	A53001-Up	SAA6D170E-2		Click Here for Your Engine
WA700-1	10001-Up	SA6D170-A-1Q	13144-14593	Click Here for Your Engine
WA700-1	10001-Up	SA6D170-A-1Q	14594-Up	Click Here for Your Engine
WA700-1-A / 1-R	10001-Up	SA6D170-A-1Q	13144-Up	Click Here for Your Engine
WA700-1L	A20001-Up	SAA6D170-E-2B	17389-Up	Click Here for Your Engine
WA700-3 / 3D	50001-Up	SAA6D170-E-2C	17389-Up	Click Here for Your Engine
WA700-3 / 3D	50001-Up	SAA6D170E-3C	310005-Up	Click Here for Your Engine
WA700-3L	A50001-Up	SAA6D170ZE		Click Here for Your Engine
WA800-1	10001-Up	SA8V170-1C	10040-Up	Click Here for Your Engine
WA800-2	10001-Up	SA12V140-1A-80	10002-Up	Click Here for Your Engine
WA800-2LC	A20020-Up	SA12V140Z-1		Click Here for Your Engine
WA800-3	50001-Up	SA12V140-1R	11640-Up	Click Here for Your Engine
WA800-3LC	A50001-Up	SAA12V140		Click Here for Your Engine
WA900-1	10001-Up	SA12V140-1P	10002-Up	Click Here for Your Engine
WA900-1L	A20001-A20007	SA12V140-1		Click Here for Your Engine
WA900-1LC	A20008-Up	SA12V140Z-1		Click Here for Your Engine
WA900-3	50001-Up	SA12V140-1S	11640-Up	Click Here for Your Engine
WA900-3LC	A50001-Up	SAA12V140		Click Here for Your Engine
WA1200-3	50001-Up			Please Contact Us 1-855-474-9400
WD500-3	50001-Up	S6D140E-2A	23227-Up	Click Here for Your Engine
WD600-1	10001-Up	S6D170-1G	10490-Up	Click Here for Your Engine
WD600-3	50001-Up	SAA6D170E-3B-8	310001-Up	Click Here for Your Engine